


# Straight A2K-FFC Installation Instructions


#### **Tools Required:**

Stanley knife
Wire cutters
Wire strippers
2mm flat head screw driver



### **Step One:**

Disassemble the Field Fit Connector and slide the base nut, securing gland, plastic collar and main body of the connector over the cable (See Fig.1)




#### **Step Two:**

Screw the base nut(with the securing gland and plastic collar fitted inside it) to the main body of the connector tight enough that it doesn't move during installation.

Strip back 25mm from the outer sheath of your DeviceNet cable to expose the wires and then remove the screens.

Cut 10mm off of the blue (NET-L) wire, leaving 15mm, as this fits to the terminal that sits higher than the others on the screw head.




#### **Step Three:**


Loosen the individual screws on each pin and insert the correct wire in accordance with Table.1 and Fig.2 one at a time.

Tighten the terminal screws as firmly as possible to secure the wire inside the pin.

Table.1

Wire Colour	Connector Pins	Name
Green/Bare	Pin 1	Shield
Red	Pin 2	NET-S
Black	Pin 3	NET-C
White	Pin 4	NET-H
Blue	Pin 5	NET-L





## **Step Four:**

Loosen off the base nut from the main body of the connector enough so it can be moved up and down the cable.

Locate the keyway inside the main body and the screw head and line them up.

Screw the main body and screw head firmly together.

Secure the base nut to ensure a watertight connection.

